

# INSTALLATION MANUAL

## 安装手册


Remote Control

遥控器


# 安装前确认

## ■ 概览


### 遥控器 A




### 遥控器 C



### 遥控器 B




### 遥控器 D




## 安装前确认

### ■ 所需工具 (自备)




### ■ 安装位置参考


 方便使用位置的参考范围



# 安装步骤


**A****B**

1




适用于遥控器 A


①




②



③




2




# 安装步骤

3    
ø 6 mm 32 mm




4




5 适用遥控器 A


①




②



③




④




# 安装步骤

## 适用遥控器 B


①




②




③




④



6



7




# 安装步骤


8



≥55min




9



10  选装


①




②



③









④




# 安装步骤

## C-1 推荐安装方式




# 安装步骤

3




4




5


①




②



③




④



# 安装步骤


6




8




≥ 55min



7




9




# 安装步骤

## 10 选装


①




②



C-2




1




# 安装步骤


2




4



3




5




# 安装步骤


## D




2    
ø 6 mm 32 mm



1 




3




# 安装步骤

4


①




②




③




④



5



6




# 安装步骤


7



≥55min



8




9




选装

①



②



# AXENT

Tel: 800 820 9880 400 888 9880

E-mail: [service@axentbath.com](mailto:service@axentbath.com) [www.axentbath.com](http://www.axentbath.com)