

INSTALLATION MANUAL

安装手册


Remote Control

遥控器


安装前确认

■ 概览


遥控器 A




遥控器 C



遥控器 B




遥控器 D





安装前确认

■ 所需工具 (自备)




■ 安装位置参考

 方便使用位置的参考范围




安装步骤

A | **B**




1




适用于遥控器 A


①




②





③




2




安装步骤

3  
ø 6 mm 32 mm




4




5 适用遥控器 A


①




②



③




④




安装步骤

适用遥控器 B


①




②




③




④



6



7




安装步骤


8



≥55min




9




10  选装


①




②



③









④




安装步骤

C-1 推荐安装方式




安装步骤

3




4




5


①




②



③




④



安装步骤


6




8




≥ 55min



7




9




安装步骤

10 选装


①




②



C-2




1




安装步骤


2




4



3




5




安装步骤



D




2  
ø 6 mm 32 mm



1 




3




安装步骤

4


①




②




③




④



5



6




安装步骤


7



≥55min




8




9  选装

①



②



AXENT

Tel: 800 820 9880 400 888 9880

E-mail: service@axentbath.com www.axentbath.com